

If You Have Any Questions Please Contact Us At: 617-755-4622 or harry@crankstopper.com

Attach: Retro-fit clamps to goal posts.


Note: Move any net lacing that may interfere with retrofit clamps.

With goal in upright position attach retrofit clamps (K) to the uprights of your goal, making sure they're oriented with "TOP" label at the top and bolt heads facing the outside of the goal. Left bracket should be mounted at approximately 7:00 and the right bracket at 5:00. Temporarily tighten clamp bolts using the Allen wrench. This setting is an approximation. The most important factor is that both clamps be set at the same height & angle.



Use self-tapping screws and a Phillips head screw driver or electric drill to attach clamp to the goal uprights. It is easier to set the screws. It is easier to screw into if goal is laid face down. Be careful not to put all the weight on the clamps. This may cause them to shift out of the desired angle.

Note:
We recommend that 4 screws are used on each retro-fit clamp.



Warning: Failure to do this can result in misalignment of CrankStopper and possible breakage.

If You Have Any Questions Please Contact Us At: 617-755-4622 or harry@crankstopper.com

After both retro fit clamps (k) have been attached lay goal on its face.

Bring both the arms (G #6) into position pictured below.

Insert the pins into their holes. This will keep the arms in the upright position as shown below.



Bring (G #6) to 90 degrees and insert (E #10) into T-Fitting. Repeat on other side.

This will keep the T-Fitting from moving out of correct alignment position.



Note: *T-Fittings have been shipped attached to both (G #6) & (G3 #8)


Please make sure that the push pins on s-curved pipe (E) are facing the back of goal away from player.



If You Have Any Questions Please Contact Us At: 617-755-4622 or harry@crankstopper.com

Use bungee loops to fasten netting to the top tube assembly. Space bungee loops at about 10-12" intervals on top bars #6 (2) & # 8

Other options are to weave rope to use plastic tie wraps.



Attach bungee loops to goal post and crossbar once upright and stabilized.



***Note: DO NOT attach any bungee loops to the Curved "S" Pipes (E).**

If You Have Any Questions Please Contact Us At: 617-755-4622 or harry@crankstopper.com

With an assistant, stand the goal upright. With one person holding front of goal up, add ballast to the back of the goal to prevent tipping.

Included with CrankStopper are ballast bags that can be filled with water or sand.

****Please make sure there is a minimum of 50lbs on the back of goal to keep it from falling forward.**

When not in use CrankStopper can be laid face down. This is recommended for overnight when not in use.

Please pay attention to weather forecasts for moderate to high wind warnings. It is best to lay goal & CrankStopper face down for safe keeping.

Also if you plan to be away from home or where you are using the CrankStopper we have found it best to lay goal & CrankStopper face down to avoid damage.